



Formulary

March 2021 Newsletter - "Pamper Yourself Naturally"



Product Description: Bath Bomb

Phase	Trade Name	INCI Name	Supplier	Formula # 214-80
A	Baking soda	Sodium Bicarbonate	Arm & Hammer	53.43
	Citric Acid	Citric Acid	Bramble Berry	9.95
	Epsom Salt	Magnesium Sulfate	Dr. Teals	31.40
B	Lavender Essential Oil	Lavandula angustifolia (Lavender) Flower Oil	Ola Prima	0.45
	NOO	Natural Octyldodecyl Oliviate	Sandream Impact	1.45
	Witch Hazel	Hamamelis Virginiana Water	T.N. Dickinson's	3.26
C	SD Tumeric Oleoresin Pigment O	Oryza Sativa Rice Bran Protein, Curcuma Longa Turmeric Root Extract, Citric Acid	Sandream Impact	0.06
TOTAL PERCENT				100.00

Procedure: Weigh all of phase A in a large bowl. Mix well with Kitchenaid type flat beater blade until all uniform. Premix phase B in a separate beaker. Add phase C (the natural pigment) to phase B and dissolve it well by mixing. Add the premixed phase B and C to phase A. Mix until all uniform. Fill into bath bomb molds. Press the mold together. Wait 2 minutes and take out the bath bombs from the molds. Place into desired packaging.

The information provided is furnished without warranty, expressed or implied, except that it is accurate to the best knowledge of Sandream Impact LLC. Customers should utilize formulations provided as a guide and perform in-house stability, micro and other necessary testing.