

Majestic Lipgloss Base Coat

Lab # NB#222-17

| Phase | RM (Trade Name) | INCI Name | Supplier Name | A | B | C | D |
|-------|-------------------------------|-------------------------|-----------------|-------|-------|-------|-------|
| A | ClearSyn 300 | Hydrogenated Polydecene | Sandream | 54.46 | 54.46 | 54.46 | 54.46 |
| A | ClearSyn 150 | Hydrogenated Polydecene | Sandream | 15.59 | 15.59 | 15.59 | 15.59 |
| A | NOO | Octyldodecyl Oleate | Sandream | 3 | 3 | 3 | 3 |
| A | Jarcol I-23CG | Octyldodecanol | Jarchem | 4.39 | 4.39 | 4.39 | 4.39 |
| A | Microcrystalline Wax SP-16W-P | Microcrystalline Wax | Strahl & Pitsch | 3.58 | 3.58 | 3.58 | 3.58 |
| A | Paraffin Wax HC | Paraffin Wax | Multiceras | 2.68 | 2.68 | 2.68 | 2.68 |
| A | Vitamin E | Tocopheryl Acetate | Sandream | 1.21 | 1.21 | 1.21 | 1.21 |
| A | Propyl Paraben | Propyl Paraben | Sandream | 0.09 | 0.09 | 0.09 | 0.09 |
| | | | | | | | |
| B | Majestic Dragonfruit | Mica, Red 27 | Sandream | 15 | | | |
| B | Majestic Pink Grapefruit | Mica, Red 30 | Sandream | | | | 10 |
| B | Majestic Pomegranate | Mica, Red 28 | Sandream | | 15 | 10 | |
| B | Majestic Plum | Mica, Manganese Violet | Sandream | | | 5 | |
| B | Majestic Carrot | Mica, Yellow 6 Lake | Sandream | | | | 5 |
| | | | Total | 100 | 100 | 100 | 100 |

Procedure

- 1 Weigh all of phase A into a glass beaker and heat to 85C.
- 2 Mix with propeller and continue mixing until all raws are dissolved and solution is homogenous.
- 3 Add Phase B and slowly mix until batch is uniform.
- 4 Stir and pour into desired pots or vials

GlassMira Lipgloss Top Coat

Lab # NB#222-17

| Phase | RM (Trade Name) | INCI Name | Supplier Name | A | B |
|-------|-------------------------------|---------------------------------|-----------------|-------|-------|
| A | ClearSyn 300 | Hydrogenated Polydecene | Sandream | 54.46 | 54.46 |
| A | ClearSyn 150 | Hydrogenated Polydecene | Sandream | 15.59 | 15.59 |
| A | NOO | Octyldodecyl Oleate | Sandream | 3 | 3 |
| A | Jarcol I-23CG | Octyldodecanol | Jarchem | 4.39 | 4.39 |
| A | Microcrystalline Wax SP-16W-P | Microcrystalline Wax | Strahl & Pitsch | 3.58 | 3.58 |
| A | Paraffin Wax HC | Paraffin Wax | Multiceras | 2.68 | 2.68 |
| A | Vitamin E | Tocopheryl Acetate | Sandream | 1.21 | 1.21 |
| A | Propyl Paraben | Propyl Paraben | Sandream | 0.09 | 0.09 |
| | | | | | |
| B | GlassMira BGG87 | Al.Ca. Na. Silicate, TiO2, SnO2 | Sandream | 15 | |
| B | GlassMira RVB86 | Al.Ca. Na. Silicate, TiO2, SnO3 | Sandream | | 15 |
| | | | Total | 100 | 100 |

Procedure

- 1 Weigh all of phase A into a glass beaker and heat to 85C.
- 2 Mix with propeller and continue mixing until all raws are dissolved and solution is homogenous.
- 3 Add Phase B and slowly mix until batch is uniform.
- 4 Stir and pour into desired pots or vials