

Formulary July 2021 Newsletter- "Tickled Pink" New Sachet CF Pinks

Product Description: High Shine Lip Gloss

| Phase | Trade Name | INCI Name | Supplier | Formula # 215-03 | Formula # 215-06 |
|---------------|----------------------------------|--|----------------------|---------------------|---------------------|
| Α | ClearSyn 300 | Hydrogenated Polydecene | Sandream Specialties | 54.45 | 54.45 |
| | ClearSyn 150 | Hydrogenated Polydecene | Sandream Specialties | 15.59 | 15.59 |
| | Octyldodecyl Olivate | Octyldodecyl Oleate | Sandream Specialties | 3.00 | 3.00 |
| | Jarcol I20CG | Octyldodecanol | Jarchem | 4.39 | 4.39 |
| | Microcrystalline Wax SP-16W-P | Microcrystalline Wax | Strahl&Pitsch | 3.58 | 3.58 |
| | Paraffin Wax HC | Paraffin Wax | Multiceras | 2.68 | 2.68 |
| | Vitamin E Acetate | Vitamin E Acetate | Sandream Specialties | 1.21 | 1.21 |
| В | Propyl Paraben | Propyl Paraben | Sandream Specialties | 0.10 | 0.10 |
| С | Sachet CF Rose (S8183) | Synthetic Fluorphlogopite, Titanium Dioxide, Iron Oxides, Tin Oxide | Sandream Specialties | 15.00 | |
| | Sachet CF Magenta (S8193) | Synthetic Fluorphlogopite, Titanium Dioxide, Iron Oxides, Tin Oxide | Sandream Specialties | | 15.00 |
| TOTAL PERCENT | | | | 100.00 | 100.00 |

Procedure: Weigh all of phase A into glass beaker and heat to 85°C. Mix with propeller and continue mixing until all raws are dissolved and solution is homogenous. Add phase B and slowly mix until dissolved and uniform. Add Phase C to A & B, propeller mix slowly until completely dispersed and smooth consistency, maintaining 85°C. Stir and pour into desired pots or vials.

The information provided is furnished without warranty, expressed or implied, except that it is accurate to the best knowledge of Sandream Specialties. Customers should utilize formulations provided as a guide and perform in-house stability, micro and other necessary testing.