



Number #: 216-66

Name: Sachet Blaze Amber Lip Gloss

Category: Newsletters

Date: 07/05/2022

No	Phase	Trade Name	INCI	%
1	A	ClearSyn 300	Hydrogenated Polydecene	54.45
2	A	ClearSyn 150	Hydrogenated Polydecene	15.59
3	A	NOO	Natural Octyldodecyl Oliviate	3.00
4	A	Jarcol I20CG	Octyldodecanol	4.39
5	A	Microcrystalline Wax SP-16W-P	Microcrystalline Wax	3.58
6	A	Paraffin Wax HC	Paraffin Wax	2.68
7	A	Vitamin E	Tocopheryl Acetate	1.21
8	B	Propyl Paraben	Propyl Paraben	0.10
9	C	Sachet Blaze Amber	Synthetic Fluorphlogopite, Iron Oxides	15.00
Total				100%
Procedure	Weigh all of phase A into glass beaker and heat to 85°C. Mix with propeller and continue mixing until all raws are dissolved and solution is homogenous. Add phase B and slowly mix until dissolved and uniform. Add Phase C to A & B, propeller mix slowly until completely dispersed and smooth consistency, maintaining 85°C. Stir and pour into desired pots or vials.			

The information provided is furnished without warranty, expressed or implied, except that it is accurate to the best knowledge of Sandream Specialties LLC. Customers should utilize formulations provided as a guide and perform in-house stability, micro and other necessary testing.