

Glamour Glitter Body Gel- Mermaid Blue

Lab # 223-42

Phase	Name	INCI	Function	Supplier	%
A	DI Water	Water	-	-	86.36
	Vanzan® NF	Xanthan Gum	Thickener	Vanderbilt Minerals	1.29
	Glycerin 99.7% USP	Glycerin	Humectant	Univar	3.00
B	Covacryl P-12	Acrylates Copolymer	Thickener	Sensient	3.00
	Euxyl PE® 9010	Phenoxyethanol	Preservative	Schulke	1.00
	DL- Panethenol	DL- Panethenol	Preservative	Sandream Specialties	0.20
C	Glamour Party Blue	Calcium Aluminum Borosilicate, Titanium Dioxide, Tin Oxide, Ferric Ferrocyanide	Pearl	Sandream Specialties	2.63
	Glamour Party Green	Calcium Aluminum Borosilicate, Titanium Dioxide, Tin Oxide, Iron Oxide Red, Ferric Ferrocyanide	Pearl		2.52
Total					100.00

Procedure

1	Add Phase A to a beaker and propeller mix at 500 rpm until uniform.
2	Add Phase B to the beaker and continue mixing at 500 rpm until uniform.
3	Add Phase C to the beaker and mix at 300 rpm until texture is smooth.
4	Adjust pH if necessary and pack into airless containers.

Notes

pH 6.5-7